

Instructions: Installation of a Mini Wall Anchor

1. Position the Mini Wall Anchor at the desired location on the wall and mark out holes with a pencil. You can also use the attached template as a guide. We recommend installing the Mini Wall Anchor at a height of 50cm measured from the bottom of the anchor to the ground. If installed on brick work, position the anchor so that the bolt holes will be drilled in the middle of the brick, not in the brick joints.
2. Drill 2 x 12mm holes deep enough to fit the fixings, ensure these holes are in a straight line.
3. Take the fixings apart, then attach and reassemble them to the back of the Mini Wall Anchor. Make sure you do not tighten the fixings as it will cause them to expand.
4. Insert the Mini Wall Anchor with the fixings into the holes. Tap the anchor gently until it is flush against the wall.
5. Use the allen key to tighten up the fixings to secure the bracket.
6. If you require Mini Wall Anchor to be permanently installed, hammer the ball bearings into the hex hole of the fixings.

Note: the fixings can no longer be undone. To remove, use an angle grinder to cut the ball bearing out so that the allen hole can be accessed.

Parts included:

- 1x Mini Wall Anchor
- 2x Fixings
- 2x Ball bearings
- 1x Instruction sheet

Tools required:

- Electric drill with 12mm bit
- Pencil
- Allen key
- Hammer

